

EyeNote™ Technical FAQ

Updated 4/20/2011

1. I have an iPhone® but the Privacy vibration does not apparently work; it only beeps?

Go to Settings, then Sounds. There are 2 Vibrate setting switches on this screen. At the top of the Sounds screen there is Silent, with a vibrate switch setting; this switch does not matter for the EyeNote™ to vibrate. Scrolling down the screen there is another Vibrate switch just above Ringtone. This Vibrate setting has to be set to ON for EyeNote to vibrate on an iPhone®.